

CVC, CV, CVL, CVLL

Typ		Model	Tuhost pružiny (N/mm)																					
A, B, C, D, E, F, G, H,	CVC	7,4	9,8	12,3	17,2	22,6	29,4	39,2	53,9	71,1	93,2	122,6	161,8	215,7	284,4	382,5	509,9	686,5	921,8	1225,8	1667,1			
A, B, C, D, E, F, G, H,	CV	3,7	4,9	6,1	8,6	11,3	14,7	19,6	27,0	35,5	46,6	61,3	80,9	107,9	142,2	191,2	255,0	343,2	460,9	612,9	833,6			
A, B, C, D, E, F, G, H,	CVL	1,8	2,5	3,1	4,3	5,6	7,4	9,8	13,5	17,8	23,3	30,6	40,5	53,9	71,1	95,6	127,5	171,6	230,5	306,5	416,8			
A, B, C, D, E, F, G, H,	CVLL	1,2	1,6	2,0	2,9	3,8	4,9	6,5	9,0	11,8	15,5	20,4	27,0	36,0	47,4	63,7	85,0	114,4	153,7	204,3	277,8			
Velikost:		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20			
Model																								
		◀Bezpečnostní zóna																						
		Zatížení (kN) ▲																						
		Posuvy (mm) ▼																						
		Bezpečnostní zóna ▶																						
																								
		Velikost:																						
		CVC	CV	CVL	CVLL																			
		0	0	0	0																			
		2,5	5	10	15																			
5	10	20	30																					
7,5	15	30	45																					
10	20	40	60																					
12,5	25	50	75																					
15	30	60	90																					
17,5	35	70	105																					
20	40	80	120																					
22,5	45	90	135																					
25	50	100	150																					
27,5	55	110	165																					
30	60	120	180																					
32,5	65	130	195																					
35	70	140	210																					
37,5	75	150	225																					
40	80	160	240																					
42,5	85	170	255																					
45	90	180	270																					
																								
		Velikost:																						
		CVC	CV	CVL	CVLL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
				M12	M12	M12	M12	M12	M16	M16	M16	M16	M20	M20	M24	M24	M30	M30	M36	M36	M42	M48	M56	M64
Závěťová řř:																								